

T-Mobile

Welcome

Start Guide

T-Mobile





alcatel
GO FLIP™ 3

TABLE OF CONTENTS

Phone Overview	1	Web Browsing	20
My Carrier	3	Bluetooth®	20
SIM Card	4	Protect Your Phone	21
Battery	6	Caring For Your Phone	23
Battery Management	7	Accessories	23
Power	8	Approved Firmware Versions	24
Home Screen	8	Device Security	24
Calls	11	Additional Information	25
Emergency call	13	1 Year Limited Warranty	25
Access Files	14	Safety and use	29
Voicemail	14	Safety tips	44
Volume & Ringtone	15		
Contacts	15		
E-Mail	17		
Text Messaging	17		

PHONE OVERVIEW



MY CARRIER

This guide provides you with information you need to get started.

For more information and additional support, please visit <https://t-mobile.com/support> where you can:

- Register at my.t-mobile.com to check your usage, pay your bill, upgrade your phone, and change your rate plan.
- Review your phone's User Manual.
- View the latest troubleshooting instructions in the Support Forums or ask a question of your own.

Service or use is your agreement to T-Mobile's Terms and Conditions. **T-Mobile requires Arbitration of Disputes unless, for new customers, you opt-out within 30 days or for existing customers, you previously opted-out.** Failure to activate service within 30 days from purchase will also be considered acceptance. For details, see T-Mobile's Terms and Conditions at [T-Mobile.com/terms-conditions](https://t-mobile.com/terms-conditions).


SIM CARD

The SIM (Subscriber Identity Module) card identifies your phone to the wireless network. You cannot make or receive phone calls without a properly installed SIM card unless its an emergency call (911).

Insert/Remove the Nano SIM and microSD Cards⁽¹⁾


1. Detach the Nano SIM card from its packaging as shown below.

Note: Nano SIM is smallest SIM size available on card.




⁽¹⁾ microSD Cards are sold separately.


2. Power off your phone, remove the back cover via the notch at the bottom-left of the phone.



3. Remove the battery from the back of the phone.



4. To insert a SIM or microSD card, push the SIM or microSD card into the card slot with the gold-colored contacts facing down. To remove the SIM or microSD card, push down the plastic spring and pull the SIM or microSD card out.




BATTERY

To optimize battery performance, be sure to fully charge your phone before using it for the first time.

Charge the Device

1. Insert the small end of the charging cable into the charge port as shown.





2. Connect charger to power outlet.


BATTERY MANAGEMENT

Optimize Battery Life

To optimize battery life, adjust your screen brightness and display timeout.


1. From the Home screen, press the **Center Soft Key** , select **Settings**  and then press the **Navigation key** to select **Personalization**.
2. Press up or down on the **Navigation key** and select **Display**.
3. Adjust **Brightness** and **Screen Timeout** to optimize battery life.

POWER

To turn the power on/off, press and hold the **End/Power Key** .

HOME SCREEN















Press the **End/Power Key**  to get instant access to the Home screen.




Status Bar



The Status bar appears at the top of your Home screen. You will find icons indicating your phone's status and new notification alerts will also appear in the Status bar.






Icon	Status
	Bluetooth® active
	Wi-Fi® active
	Vibrate
	Network (full signal)
	Network (roaming)
	4G LTE data service
	3G data service
	Airplane mode
	Alarm set
	Battery (charging)
	Battery (full charge)
	Missed call
	New mail
	New message

App List

From the Home screen, press the **Center Soft Key**  to access the **App list**.










Change Home Screen Wallpaper


1. From the Home screen, press the **Center Soft Key** , select **Settings**  and then press the **Navigation Key** to select **Personalization**.
2. Press the **Navigation Key** and select **Display** -> **Wallpaper**. Select the image location to browse from **Wallpaper**, **Gallery** or **Camera**.
3. Select new image, press the **Right Soft Key**  to save. Exit out and new image will be displayed on the Home screen.

CALLS



Make a Call

Dial the desired number and press the **Call Key**  to place the call, or press the **Right Soft Key**  to select a contact from **Contacts**, and then press up or down on the **Navigation Key** to select the desired contact and press the **Call Key** . If you make a mistake, you can delete the incorrect digits by pressing the **End/Power Key** . To hang up the call, press the **End/Power Key** . Press the **Right Soft Key**  to select more options.



The number you entered can be saved to **Contacts** by pressing the **Right Soft Key**  while on the dial screen and select **Create new contact**.


International Call

To dial an international call, press  key twice to enter “+”, then enter the international country prefix followed by the full phone number and finally press the **Call Key** .





Emergency Call

If your phone has network coverage, dial emergency number and press the **Call Key**  to make an emergency call. This works even without a SIM card.

Answer or Decline a Call



When you receive a call:

- Press the **Left Soft Key**  or **Call Key**  to answer;
- Press the **Right Soft Key**  or **End/Power Key**  to decline.

To mute the ringtone volume of an incoming call, press the **Volume Key**.

EMERGENCY CALL

Although all phones are equipped with 9-1-1 emergency calling capabilities, this phone may or may not permit its location to be approximated during a 9-1-1 call.*

*Availability of this feature depends on upgrades to the (a) wireless network and (b) 9-1-1 calling system that are required to be installed by the local 9-1-1 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped, or refused. The phone's approximate location is transmitted to the local 9-1-1 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a mobile phone for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions, and Privacy Policy for additional service restrictions and details.

ACCESS FILES

To access media files and photos saved on your handset or to transfer files from your handset's SD card to your computer, follow these steps:


Connect Device to PC

1. Enable **USB Storage** in **Settings** -> **Storage** -> **USB Storage**.
2. Use micro-USB connector to connect your phone to your computer.
3. Use your computer's operating system to find phone to access files or SD card.

This phone is compatible with Windows® XP, Windows® 7, Windows® Vista, Windows® 8, Windows® 10, Linux and Mac OS®.

VOICEMAIL

Set Up Voicemail



1. Press and hold **1**  to call voicemail.
2. Follow the prompts to set up your voicemail account.

VOLUME & RINGTONE

Adjust In-call Volume





While on a call, press the **Volume Up/Down Key** to adjust volume.



Adjust Ringtone and Volume

1. From the Home screen, press the **Center Soft Key** , select **Settings** , and then press the **Navigation Key** to select **Personalization**.
2. Press the **Navigation Key** to select **Sound**.
3. Select **Tones** -> **Ringtones** to choose the desired ringtone.
4. Select **Volume** option to adjust volume for Media, Ringtones, or Alarm.




CONTACTS

Create a New Contact




1. From the Home screen, press the Right Soft Key , or press the **Center Soft Key**  and select **Contacts** .
2. Press the **Left Soft Key**  to create a new contact.

3. Enter contact's name and other contact information. You can use your voice to enter information, simply press and hold the **Center Soft Key**  to activate the Google Assistant.
4. When finished, press the **Center Soft Key**  to save.

Add a Contact from Call History Log




1. Access your call history log by pressing the **Call Key**  from the Home screen.
2. Press the **Navigation Key** to select the number you want to save to contacts on the call history screen.
3. Press the **Right Soft Key**  to open the **Options** menu.
4. Press the **Navigation Key** to select **Create new contact** or **Add to existing contact**.
5. Enter contact's information and press the **Center Soft Key**  to save.

Make a Call from Contact List

1. From the Home screen, press the **Center Soft Key**  and select **Contacts** .
2. Press the **Navigation Key** to select the contact and press the **Center Soft Key** , dialing will start immediately.

E-MAIL





Set Up Email Accounts



1. From the Home screen, press the **Center Soft Key**  and select **E-mail** .
2. Enter the account name, Email address and password. You can use Google Assistant to use your voice to input your name.
3. Press the **Left Soft Key**  to go to **Advanced** options.


TEXT MESSAGING

Use the messaging feature to send and receive text (SMS) and multimedia (MMS) messages.

Create and Send a Message

1. From the Home screen, press the **Center Soft Key**  and select **Messages**  to enter **Messages**.
2. Press the **Left Soft Key**  to write a new text message.
3. Enter the phone number of the recipient in the bar at the top of the page or press the **Right Soft Key**  to add recipients.


4. Press the **Navigation Key** to go to the **Message** bar to write a text message, or press and hold the **Center Soft Key**  to use your voice to input the content of the message.
5. Press the **Left Soft Key**  to send text messages.





Use Your Google Assistant

Need to get something done? Just press a button and ask!

Launch your Google Assistant

1. From the Home screen, press and hold the **Center Soft Key**  to launch your **Google Assistant**, or press the **Navigation Left Key** to access your **Google Assistant**.
2. Once the "Listening..." screen appears, say your voice command out loud. Your **Google Assistant** will speak back to you and walk you through the next steps.


Use Google Assistant to Make a Call

- Call a contact: Press and hold the **Center Soft Key** , then say "Call Katie." Your phone will call Katie from your Contacts.
- Call a number: Press and hold the **Center Soft Key** , then say "Call 998-321-1234." Your phone will dial the number.

What else can your Google Assistant do?


- Open an app: "Open E-Mail."
- Get the weather: "What's the weather in Atlanta today?"
- Send a text: "Send a text to Katie."
- Find a local business: "Find a pizza place."
- Find out what else your Google Assistant can do: "What can you do?"






Send a Multimedia Message

MMS enables you to send video clips, images, photos, contacts and sounds to other compatible phones and email addresses by pressing the **Right Soft Key**  from the the text messages screen and then selecting **Add attachment**.

An SMS will be converted to MMS automatically when media files (image, video, audio, etc.) are attached or email addresses are added.

WEB BROWSING






1. From the Home screen, press the **Center Soft Key**  and select **Google Browser** .
2. Press the **Left Soft Key**  and enter the website you want to browse, then press the **Center Soft Key**  to search. You can also use Google Assistant to use your voice to input a web address.
3. To access the **Options** menu, press the **Right Soft Key** .

BLUETOOTH®

Your phone comes with Bluetooth connectivity, a wireless technology that enables a data connection between your phone and a Bluetooth headset or other Bluetooth device (sold separately).



Connect to Bluetooth


1. From the Home screen, press the **Center Soft Key**  and select **Settings** .
2. Use the **Navigation Key** to select **Network & Connectivity** -> **Bluetooth**.
3. Using the **Navigation Key**, select **On** and press the **Center Soft Key**  to turn Bluetooth on.
4. The phone will automatically search for Bluetooth-enabled devices by pressing **Nearby Devices**.
5. Select the desired Bluetooth device to pair with phone.


PROTECT YOUR PHONE

Add a security PIN to prevent others from using your phone without your permission.

Activate Security PIN



1. From the Home screen, press the **Center Soft Key** , select **Settings** , and then press the **Navigation Key** to select **Privacy & Security**.
2. Press the **Navigation Key** and select **On** to enable screen lock on the **Screen Lock** screen.

3. Enter the passcode twice and press the **Right Soft Key**  to create.



Deactivate Security PIN

Note: Be sure to deactivate this option before you return or exchange your phone or before factory reset to avoid PIN from being required to access phone.

1. From the Home screen, press the **Center Soft Key** , select **Settings** , and then press the **Navigation key** to select **Privacy & Security**.
2. Press the **Navigation key** to select **Off** to disable screen lock on the **Screen Lock** screen.
3. Enter the passcode to confirm removal.

CARING FOR YOUR PHONE

Make it Last

Your phone is a complex electronic device; think of it as a mini-computer. Here are a few tips to help you extend the life of your new phone.

Do not get your phone wet. Even a small amount of moisture can damage your phone and accessories.

Protect your phone's screen. Your phone's screen is delicate.

Use the original manufacturer's batteries and accessories. Non-approved batteries and accessories can harm you and damage your phone.

Do not use damaged accessories. If your charger or any other accessory is damaged, please replace it. Do not attempt to charge your phone if the charger has been dropped, received a sharp blow, or has been otherwise damaged; doing so may damage your phone.

ACCESSORIES

Whether you want a charger, or a fashionable headphone, T-Mobile is the shop for all your phone accessories.

To purchase accessories for your phone, please visit T-Mobile.com, call **1.800.204.2449**, or visit your nearest T-Mobile store.

Accessories selection subject to change and may vary by location.

APPROVED FIRMWARE VERSIONS

This device will only operate with firmware versions that have been approved for use by T-Mobile and the device manufacturer. If unauthorized firmware is placed on the device, it will not function.

DEVICE SECURITY

T-Mobile encourages customers to take appropriate measures to secure their handsets and invites them to take advantage of the features available on this handset to help secure it from theft and/or other unauthorized access and use. This handset has a locking function (e.g., Security PINs) that can serve as a first line of defense against unauthorized use or access to stored information. Preloaded security applications that allow customers to track or locate misplaced devices can be found on several T-Mobile devices. Lost or stolen devices should be immediately reported to T-Mobile so that proper measures can be taken to protect accounts. For additional information, visit: www.tmobile.com/devicesecurity and <http://www.t-mobile.com/Company/PrivacyResources.aspx>.

ADDITIONAL INFORMATION

Use of some content or features may require qualifying service or access to a Wi-Fi connection.

Wi-Fi: Devices using wireless connections may be vulnerable to unauthorized attempts to access data on the device. Plan data allotment applies to use by connected devices sharing Wi-Fi. Use of connected devices are subject to T-Mobile's Terms and Conditions

Devices and screen images are simulated. **Coverage** not available in some areas. Visit T-Mobile.com for **Terms and Conditions (including arbitration provision)**, rate plan information, charges for features and services, coverage details, and restrictions.

The Bluetooth® word mark and logo are owned by Bluetooth SIG, Inc. and are used by T-Mobile under license. T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG.

1 YEAR LIMITED WARRANTY

TCT Mobile Inc., offers a 1 year limited warranty on all TCL and Alcatel devices that are found to be defective in materials or workmanship upon submission of the following items:

1. Proof of purchase – consisting of original invoice or sales slip indicating the date of purchase, dealer's name, model and serial number of the product.

General Terms and Conditions

This warranty is confined to the first purchaser of the product only and is not applicable to cases other than defects in material, design and workmanship.

Items and Conditions Not Covered:

- Damages resulting from normal wear and tear and/or the need for regular maintenance shall not constitute a defect under the terms of this warranty.
- Abuse or misuses, including but not solely limited to the failure to use this product for its normal purposes or in accordance with TCT's instructions on usage and maintenance.
- Defects resulting from usage of the product in conjunction with accessories that are not approved by TCT for use with this product.
- TCT will not be responsible for any repairs caused by third party component parts, or service that is found to be the cause for the defect or damage of the product.
- TCT will not be responsible for failure to use the battery in accordance with the specific instructions of core outlined in the product user manual. For example, do not attempt to open sealed devices, such as batteries. Opening of sealed devices may result in bodily injury and/or property damage.
- Accidents, Acts of God, lightning, water, fire, public disturbances, improper ventilation, voltage fluctuations or any cause beyond the control of TCT.

- This warranty does not affect the consumers' statutory rights nor the consumers' rights against the dealer related to their purchase/ sales agreement.

TCT's 1 Year Limited Warranty will abide by the following options regarding claims:

1. Repair the TCT product using new or previously used parts that are equivalent to new in performance and reliability.
2. Replace the TCT product with the same model (or with customer consent a product that has similar functionality) formed from new and/or previously used parts that are equivalent to new in performance and reliability.
 - a. When a TCT product or part is replaced or provided, any replacement item becomes the customer's property and the replaced or refunded item becomes TCT's property.
 - b. TCT will not provide any data transfer service. This is the customer's responsibility. TCT shall not be liable for the loss of any saved/stored data in products that are either repaired or replaced. Customer should maintain a separate backup copy of the contents of the device's data.
3. All refund requests shall be submitted to the retailer where the device(s) were originally purchased and shall subject to the retailer's refund policies. Customers may obtain the retailers return policies at the links provided below:
 - a. U.S. <https://us.alcatelmobile.com/return-policy/>
 - b. Canada <https://ca.alcatelmobile.com/return-policy/>

4. Repair or Replacement of any TCT product under the terms of this warranty does not provide right to extension or renewal of the warranty period.
5. Warranty repairs are available free of charge at TCT authorized repair centers for products that comply with the General Terms and Conditions of this warranty. Shipping cost of the defective product(s) to TCT authorized repair center is to be paid by the customer. The customer is responsible for any damage to the defective product during shipment to the authorized repair center.
6. This warranty is not transferrable. This warranty will be the purchasers' sole and exclusive remedy and neither TCT nor its service centers shall be liable for any incidental or consequential damages or breach of any express or implied warranty of this product.
7. This warranty extends to products purchased and sold within the United States and Canada. All products sold in United States will be subject to their respective state and federal laws. All products purchased in Canada will be subject to Canadian laws.

Company Contact Information

Customer Care may be contacted at:

USA Phone Number: 855-368-0829 or
<https://us.alcatelmobile.com/>

Canada Phone Number: 855-844-6058 or
<https://ca.alcatelmobile.com/>

Electronic Recycling

For more information on Electronic Recycling:

- 1) Visit Alcatel Electronic Recycling Program website at <https://us.alcatelmobile.com/accessibility-compliance/electronic-recycling-program/>, or
- 2) Call Alcatel US Customer Support at 1-855-368-0829.

Battery Recycling (USA & Canada):

Alcatel partners with Call2Recycle® to offer a safe and convenient battery recycling program. For more information on our Battery Recycling Program, please visit the USA and Canada website at <https://us.alcatelmobile.com/accessibility-compliance/battery-recycling/> and <https://ca.alcatelmobile.com/accessibility-compliance/battery-recycling/>.



SAFETY AND USE

We recommend that you read this chapter carefully before using your mobile phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

Traffic Safety

Given that studies show that using a mobile phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their mobile phone when the vehicle is not parked. Check the laws and regulations on the use of wireless mobile phones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.

When driving, do not use your mobile phone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas.

When switched on, your mobile phone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:

- Do not place your mobile phone on top of the dashboard or within an airbag deployment area,
- Check with your car dealer or the car manufacturer to make sure that the car's electronic devices are shielded from mobile phone RF energy.

Conditions of Use

You are advised to switch off the mobile phone from time to time to optimize its performance.

Remember to abide by local authority rules of mobile phone use on aircrafts.

Operational Warnings: Obey all posted signs when using mobile devices in public areas.

Follow Instructions to Avoid Interference Problems:

- Turn off your mobile device in any location where posted notices instruct you to do so. In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.
- Switch the mobile phone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, mobile phones can interfere with other electrical or electronic devices, or equipment using radio frequency.
- Switch the mobile phone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, gas station, or chemical plant, or in any potentially explosive atmosphere.
- When the mobile phone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump. In particular when using the mobile phone you should hold it against the ear on the opposite side to the device, if any.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your mobile device with your implantable medical device, consult your healthcare provider.

To avoid hearing impairment, answer the call before holding your mobile phone to your ear. Also move the handset away from your ear while using the “hands-free” option because the amplified volume might cause hearing damage.

It is recommended to have proper supervision while small children use your mobile phone.

Do not attempt to disassemble your phone. If you disassemble your phone, the warranty will not apply.

Always handle your mobile phone with care and keep it in a clean and dust-free place.

Do not allow your mobile phone to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc.). The manufacturer’s recommended operating temperature range is 0°C (32°F) to 50°C (122°F) (the max value depends on device, materials and housing paint/texture).

Over 50°C (122°F) the legibility of the mobile phone’s display may be impaired, though this is temporary and not serious.

Do not open or attempt to repair your mobile phone yourself.

Do not drop, throw or try to bend your mobile phone.

Do not use the mobile phone if the screen is damaged, cracked or broken to avoid any injury.

Do not paint it.

Use only batteries, battery chargers, and accessories which are recommended by TCL Communication Technology Holdings Limited and its affiliates and are compatible with your mobile phone model. TCL Communication Technology Holdings Limited and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries.

Your mobile phone should not be disposed in municipal waste. Please check local regulations for disposal of electronic products.

Remember to make back-up copies or keep a written record of all important information stored in your mobile phone.

Some people may suffer epileptic seizures or blackouts when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your mobile phone. Parents should monitor their children's use of video games or other features that incorporate flashing lights on the mobile phone. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

- Play at the farthest distance possible from the screen.

When you play games on your mobile phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow these instructions to avoid problems, such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders:

- Take a minimum of a 15-minute break every hour of game playing.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.



PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

Privacy

Please note that you must respect the laws and regulations of your jurisdiction or other jurisdiction(s) where you will use your mobile phone regarding taking photographs and recording sounds with your mobile phone. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and reproduce or distribute them, as this may be considered to be an invasion of privacy.

It is the user's sole responsibility to ensure that prior authorization be obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your mobile phone (including the operator) disclaim any liability which may result from the improper use of the mobile phone.

Battery and Accessories

Following air regulation, if the battery of your product is not charged, please charge first.

Before removing the battery from your device, make sure that the device is switched off.

Observe the following precautions for battery use:

- Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not puncture, disassemble, bend, deform, open, shred or cause a short-circuit in the battery.
- Do not burn or dispose of a used battery in household garbage or store it at temperatures above 60°C.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard

The symbol below on your telephone, the battery and the accessories means that these products must be taken to collection points at the end of their life:



- Municipal waste disposal centers with specific bins for these items of equipment.
- Collection bins at points of sale.

They will then be recycled, preventing substances from being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge. All products with this sign must be brought to these collection points.

In non-European Union jurisdictions:

Types of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

In the United States, you can learn more about how to recycle your mobile device by visiting the CTIA website at www.ctia.org/news/how-to-recycle-your-mobile-device

CAUTION: IF BATTERY IS REPLACED BY AN INCORRECT TYPE, DEVICE MIGHT EXPLODE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTION.

⚠ WARNING: Cancer and Reproductive Harm -
www.P65Warnings.ca.gov

Chargers

Home A.C./Travel chargers will operate within the temperature range of: 0°C (32°F) to 45°C (113°F).

The chargers designed for your mobile phone meet the standard for safety of information technology equipment and office equipment use. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.

Characteristics of power supply (depending on the country):

Travel charger: 100-240V, 50/60Hz, 150mA

Output: 5.0 V, 550mA

Battery: Lithium 1350mAh

Radio Waves

THIS MOBILE PHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your mobile phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio-frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. These guidelines include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health.

The exposure standard for mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the Federal Communications Commission of the US Government (FCC), or by Industry Canada, is 1.6 W/kg averaged over 1 gram of body tissue. Tests for SAR are conducted using standard operating positions with the mobile phone transmitting at its highest certified power level in all tested frequency bands.

Although the SAR is determined at the highest certified power level, the actual SAR level of the mobile phone while operating can be well below the maximum value. This is because the mobile phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the mobile phone. Before a mobile phone model is available for sale to the public, compliance with national regulations and standards must be shown. The highest SAR value for this model mobile phone when tested is 1.28 W/Kg for use at the ear and 1.16 W/Kg for use close to the body.

While there may be differences between the SAR levels of various mobile phones and at various positions, they all meet the government requirement for RF exposure. For body-worn operation, the phone has been tested when positioned a minimum of 15 mm from the body without any metal parts in the vicinity of the phone or when properly used with an appropriate accessory and worn on the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. Additional information on SAR can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site: <https://www.ctia.org>.

The World Health Organization (WHO) considers that present scientific information does not indicate the need for any special precautions for use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep mobile phones away from the head and body. (fact sheet n°193). Additional WHO information about electromagnetic fields and public health are available on the following website: <http://www.who.int/peh-emf>.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For the receiver devices associated with the operation of a licensed radio service (e.g. FM broadcast), they bear the following statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

For other devices, they bear the following statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Your mobile phone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or USB data cable. If you are using another accessory, ensure that whatever product is used is free of any metal and that it positions the mobile phone at least 15 mm away from the body.

Licenses



microSD logo is a trademark of SD-3C, LLC.



The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TCL Communication Technology Holdings Limited and its affiliates is under license. Other trademarks and trade names are those of their respective owners.

Alcatel 4052W

Bluetooth® Declaration ID D044935



The Wi-Fi Logo is a certification mark of the Wi-Fi Alliance.

You have purchased a product which uses the open source (<http://opensource.org/>) programs mtd, msdosfs, netfilter/iptables and initrd in object code and other open source programs licensed under the GNU General Public License and Apache License. We will provide you with a complete copy of the corresponding source codes upon request within a period of three years from the distribution of the product by TCL Communication Technology Holdings Limited. You may download the source codes from <http://sourceforge.net/projects/alcatel/files/>.

The provision of the source code is free of charge from internet.

Hearing Aid Compatibility

Your mobile phone is rated: «For Hearing Aid», to assist hearing device users in finding mobile phones that may be compatible with their hearing devices.

This device is HAC M4/T4 compatible. Reference ANSI C63.19 (2011).

For more information please visit our website
<https://us.alcatelmobile.com/>

FCC ID: 2ACCJN032

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult you service provider or phone retailer.

E-labeling: To find more information regarding FCC ID, IMEI number, and more, go to **Settings > Device > Regulatory & Safety**.

SAFETY TIPS

Consider Device Compatibility

If you have a pacemaker or a hearing aid, check with your doctor to make sure it's safe for you to use a mobile phone. In some cases, cellular radio frequencies can disrupt the performance of other electronic equipment. If you have questions about the interaction between your phone and any other piece of electronic equipment, ask the equipment manufacturer.

Alcatel is a trademark of Nokia used under license by
TCL Communication Technology Holdings Limited.

GO FLIP is a trademark of TCL Communication
Technology Holdings Limited.

© 2019 TCT Mobile Limited.
All rights reserved.

TCL Communication Technology Holdings Limited
reserves the right to alter material
or technical specification without prior notice.

All "Signature" ringtones embedded in this phone have
been composed, arranged, and mixed by NU TROPIC
(Amar Kabouche).

Printed in China